



NOTE: TO INSTALL OR RELEASE THE BAR:
1. EXERT A SLIGHT DOWNWARD PRESSURE
ON THE PIC LEVER TO RELIEVE THE TENSION ON THE SPRING LATCHES.
2. SLIDE THE BAR INTO THE SLOTS NEXT TO THE LATCHES.
THE BAR WILL SLIDE FREELY IN OR OUT.



PART CONSISTS OF BRACKET, LOCK AND KEY.

**SLIDE BAR INTO
SLOT LOCATED HERE**



PIC HOUSING NOT INCLUDED

PROPRIETARY AND CONFIDENTIAL
THE INFORMATION CONTAINED IN THIS
DRAWING IS THE SOLE PROPERTY OF
MENCOM CORPORATION. ANY
REPRODUCTION IN PART OR AS A WHOLE
WITHOUT THE WRITTEN PERMISSION OF
MENCOM CORPORATION IS
PROHIBITED.

UNLESS OTHERWISE SPECIFIED: DIMENSIONS ARE IN INCHES AND [MM]	DRAWN BY	ADM
	DRAWN DATE	09/13/2018
	CHECKED BY	JJH
	CHECK DATE	09/13/2018
	COMMENTS:	
MATERIAL		
FINISH		
DO NOT SCALE DRAWING		

MENCOM CORPORATION		
TITLE: LOCK KIT FOR PIC SZ 06		
SIZE B	DWG. NO. D-PIC-LOCK-06	REV B
SCALE: 1:1	WEIGHT:	SHEET 1 OF 1